



GOODRIVE 350A VFD

Please read the .manual for full setting up instructions
Connection and set up must be completed by a suitably qualified person.

BASIC START UP / SPEED CHANGE GUIDE

This is just the basic quick start guide and how to change the set speed once commissioned

- 1) connect 3 phase power on to R S T terminals
- 2) connect motor to U V W terminals
- 3) turn power on
- 4) set language to English using arrow keys then press select \ key
- 5) press arrow key down to select just once
- 6) press enter
- 7) press enter again
- 8) asked to enter unit setting mode, select yes and press enter

This should take you to the homepage

From homepage you can simply alter the run speed by (see picture guide)

- 1) select menu
- 2) select parameter settings
- 3) select function code quick settings
- 4) use arrow keys to highlight P00:
- 5) P00:00 should now appear
- 6) use arrow key to set to P00:10
- 7) press select
- 8 use arrow keys to select desired output running speed in Hz upto 600 max
- 9) press confirm
- 10) press homepage

This should take you back to the homepage

Press the green button to start and run the blower at the set speed, which should be displayed on the top of the screen.

The red button will stop the blower

If a remote start is required it can be connected through common output and S1 input on the small terminal rail. (see page 28 in the manual)

