

# CENTRIFUGAL BLOWER

**AIR TEC**

AIR SYSTEMS

## PARTS LIST

ITEM	PART NAME	ITEM	PART NAME	ITEM	PART NAME
01	Flange cover	11	Motor front cover	21	Cooling fan
02	Inlet flange	12	Front bearing	22	Fan cover
03	Wire net	13	Bearing washer	23	Terminal box gasket
04	Front cover	14	key	24	Terminal box
05	Impeller washer	15	Rotor	25	Terminal board
06	Impeller	16	Stator & Coil	26	Cover gasket
07	Sleeve	17	Motor housing	27	Terminal box cover
08	seal	18	Rear bearing	28	Cable gland
09	Housing	19	Wave washer		
10	Outlet flange	20	Motor cover		

## SYSTEM DRAWING

